

Basic end caps

Project Information

Job name:	Location:
Engineer:	Date submitted:
Contractor:	Submitted by:
Manufacturer's representative:	Approved by:

Product information and application use

The Basic End Cap terminates the end of the TruFLOW™ Jr. modular manifolds. Includes required gaskets and O-rings.

The Brass Manifold Loop End Cap closes off unused QS20 loop connections.



Part name	Part no.	Material group	End Type 1	Operating Temperature 1 [°F]	Operating Temperature 2 [°F]	Operating Temperature 3 [°F]	A [inch]	B [inch]	C [inch]	Subcomponent Material	Prop 65 label required?
Basic End Cap, R32	A2080032	Brass	ISO 228-G	73	180	200	-	-	-	-	-
TruFLOW Manifold Basic End Cap	A2611250	-	-	-	-	-	1.496	1.496	0.768	-	-
Basic End Cap Gasket, spare part, R32	A2400032	Brass	ISO 228-G	73	180	200	1.58	1.58	0.125	Dezincification Resistant Brass	Yes

Part name	Part no.	D [inch]	E [inch]	Weight per UOM [lbs/UOM]
Basic End Cap, R32	A2080032	-	-	0.25
TruFLOW Manifold Basic End Cap	A2611250	0.354	1.024	-
Basic End Cap Gasket, spare part, R32	A2400032	-	-	0.01

Part name	Part no.	Codes	Standards	Listings
Basic end caps	All	-	ASTM F877	-

Installation

The Basic End Cap threads onto one end of a brass manifold. A gasket aids the seal. Do not over-tighten. The Brass Manifold Loop End Cap threads onto a brass manifold outlet. A gasket aids the seal. Do not over-tighten. For more information, refer to the Uponor Radiant Installation Handbook. Available accessories: Basic End Cap Gasket, spare part (A2400032); Loop End Gasket, spare part (A2400020).

Related applications

Radiant Heating and Cooling Systems

Footnotes

-

Contact information

Uponor Inc.
5925 148th Street West
Apple Valley, MN 55124
T 800.321.4739
F 952.891.2008

Uponor Ltd.
6510 Kennedy Road
Mississauga, ON L5T 2X4
T 888.594.7726
F 800.638.9517