

# Quik Trak combo panels

## Project information

|                                |                 |
|--------------------------------|-----------------|
| Job name:                      | Location:       |
| Engineer:                      | Date submitted: |
| Contractor:                    | Submitted by:   |
| Manufacturer's representative: | Approved by:    |

## Technical data

|                         |                                    |
|-------------------------|------------------------------------|
| Material                | Wood                               |
| Subcomponent Material   | 1/2" plywood with aluminum backing |
| Prop 65 label required? | Yes                                |

## Product information and application use

Quik Trak® Panels are designed for use with 5 /16" Wirsbo hePEX™ tubing only. The 1/2-inch plywood panels come attached to an aluminum heat-transfer sheet.



| Part name   | Part no. | A [inch] | B [inch] | C [inch] | Weight per UOM [lbs/UOM] |
|---|----------|----------|----------|----------|--------------------------|
| Quik Trak 12" x 48" Combo Panel, 6 runs with return         | A5060712 | 47.75    | 11.75    | 0.5      | 4.45                     |
| Quik Trak 12" x 12" Combo 90, 6 runs                        | A5060722 | 11.75    | 11.75    | 0.5      | 1                        |
| Quik Trak 7" x 12" Combo Access Panel, 6 runs with 1 access | A5060732 | 11.75    | 6.835    | 0.5      | 0.5                      |

| Installation  | Related applications  |
|---|---|
| Place Quik Trak Panels on floor surface, ensuring the seams are staggered. Secure one side of the panel with a screw on each end to allow for quick realignment of panels. After properly placing the panels, secure each one with ten screws (five on each side of the groove). Clean any debris from the panel grooves. Apply a thin (?) bead of 100% silicone Quik Trak Sealant (E6050010) throughout the entire length of the groove. The silicone acts as an adhesive agent, promoting good heat transfer from the tubing to the panel. Install the tubing according to the design. For additional information, refer to the Uponor Quik Trak Installation Manual and the Uponor Radiant Floor Heating Installation Handbook | Radiant Heating and Cooling Systems<br>Permafrost Protection Systems<br>Turf Conditioning Systems |

| Footnotes | Contact information  |
|-----------|--|
| -         | Uponor Inc.<br>5925 148th Street West<br>Apple Valley, MN 55124<br>T 800.321.4739<br>F 952.891.2008<br>Uponor Ltd.<br>6510 Kennedy Road<br>Mississauga, ON L5T 2X4<br>T 888.594.7726<br>F 800.638.9517 |