

# TotalFit removal tools

## Project Information

Job name:	Location:
Engineer:	Date submitted:
Contractor:	Submitted by:
Manufacturer's representative:	Approved by:

## Product information and application use

TotalFit™ is the professional-grade engineered polymer (EP) push-to connect solution that provides greater value for residential projects with the same versatility and speed as brass push-to-connect fittings for PEX, PE-RT, CPVC, and copper piping systems.



Part name	Part no.	Prop 65 label required?	Weight per UOM [lbs/UOM]
TotalFit Removal Tool, 1/2	TF4800500	No	0.01
TotalFit Removal Tool, 3/4	TF4800750	No	0.02
TotalFit Removal Tool, 1	TF4801000	-	0.02

Part name	Part no.	Codes	Standards	Listings
TotalFit removal tools	All	UPC IRC IPC NPC of Canada UMC CMC CPC IMC	NSF-372 ASTM F877 NSF-61 NSF-14 ASSE 1061	-

## Installation

Use to remove TotalFit connections from Install on PEX, PE-RT, CPVC, and copper piping systems.

1. Attach the appropriately sized removal tool to the pipe
2. Press it back against the release collar of the fitting. This will disengage the grab ring.
3. Remove the pipe from the fitting.

## Related applications

- Plumbing
- Hydronic Heating & Cooling

Refer to the Uponor TotalFit Instruction Sheet for additional information.

## Footnotes

-

## Contact information

Uponor Inc.  
5925 148th Street West  
Apple Valley, MN 55124  
T 800.321.4739  
F 952.891.2008

Uponor Ltd.  
6510 Kennedy Road  
Mississauga, ON L5T 2X4  
T 888.594.7726  
F 800.638.9517