

TruFLOW visual flow meters

Project information

Job name:	Location:
Engineer:	Date submitted:
Contractor:	Submitted by:
Manufacturer's representative:	Approved by:

Technical data

Material	Brass
End type 1	ISO 228-G 3/4"
End type 2	ISO 228-G 3/4"
Temp/pressure ratings	73 °F (23 °C) at 160 psi (11 bar) 180 °F (82 °C) at 100 psi (6.9 bar) 200 °F (93 °C) at 80 psi (5.5 bar)
Prop 65 label required?	Yes

Product information and application use

Use the TruFLOW™ Visual Flow Meter on TruFLOW Jr. and TruFLOW Classic Manifolds to accurately measure the flow of hydronic radiant loops. The meter is available in a low range (A2640015), which measures 0.15 to 0.8 gpm and a high range (A2640027), which measures 0.25 to 2.0 gpm.



Part name	Part no.	Codes	Standards	Listings
TruFLOW visual flow meters	All	-	-	-

Installation

Assemble the TruFLOW Visual Flow Meter on the return manifold and observe that the water flows in the same direction as the arrow on the body of the meter. The TruFLOW Visual Flow Meter may be installed in a vertical or horizontal position. Do not install the TruFLOW Visual Flow Meter upside-down (arrow pointing downward) as it will affect the accuracy of the reading. Do not use any solvent-based cleaner to clean the measuring windows.

Related applications

- Radiant Heating and Cooling Systems
- Permafrost Protection Systems
- Turf Conditioning Systems

Notes

Precision: +/-0.05gpm
Measuring Range: 0.15 gpm to 0.8 gpm
Connection:
R20 QS-style

Precision: +/-0.05gpm
Measuring Range: 0.40 gpm to 2.0 gpm
Connection:
R20 QS-style

Footnotes

Contact information

Uponor Inc.
5925 148th Street West
Apple Valley, MN 55124
T 800.321.4739
F 952.891.2008

Uponor Ltd.
6510 Kennedy Road
Mississauga, ON L5T 2X4
T 888.594.7726
F 800.638.9517