Brass manifold loop end caps

Project information

Job name:	Location:
Engineer:	Date submitted:
Contractor:	Submitted by:
Manufacturer's representative:	Approved by:

Technical data

Material	Brass
Temp/pressure ratings	73 °F (23 °C) at 160 psi (11 bar) 180 °F (82 °C) at 100 psi (6.9 bar) 200 °F (93 °C) at 80 psi (5.5 bar)



Product information and application use

The Basic End Cap terminates the end of the TruFLOW™ Jr. Modular Manifolds. Required gaskets and o-rings are included.

The Brass Manifold Loop End Cap closes off unused QS20 loop connections.

	Part name	Part no.	A [inch]	B [inch]	C [inch]	D [inch]	End Type 1	E [inch]	Prop 65 label required?	Weight per UOM [lbs/UOM]
	Brass Manifold Loop End Cap, R20	A2080020	1.309	1.187	0.453	0.354	ISO 228-G	-	-	0.08
✔	Brass Manifold Loop End Cap Gasket, spare part	A2400020	0.94	0.94	0.09	-	-	0.1	Yes	0

Part name	Part no.	Codes	Standards	Listings
Brass manifold loop end caps	All	-	ASTM F877	-

Installation

The Basic End Cap threads onto one end of a brass manifold. The seal is aided by a gasket. Do not over-tighten. The Brass Manifold Loop End Cap threads onto a brass manifold outlet. The seal is aided by a gasket. Do not over-tighten. For more information, refer to the Uponor Radiant Installation Handbook. Available accessories: Basic End Cap Gasket, spare part (A2400032); Loop End Gasket, spare part (A2400020)

Related applications

Radiant Heating and Cooling Systems

Footnotes

-

Contact information

Uponor Inc.
5925 148th Street West
Apple Valley, MN 55124
T 800.321.4739
F 952.891.2008

Uponor Ltd.
6510 Kennedy Road
Mississauga, ON L5T 2X4
T 888.594.7726
F 800.638.9517

© 2024 Uponor North America. All Rights Reserved