

Quick Guide to Smatrix Public Thermostat Registration

1. Remove the grey cover from the controller and ensure there is power to the controller and the power light is illuminated.



- Press and hold the OK button on the controller until the LED for channel 1 (or the first unregistered channel) Flashes red.
- Move the red flashing LED to the preferred channel which you would like to register the thermostat to using the < or >
- 4. Press the OK button to select the preferred channel. The LED will start to flash green.



- Uponer Up
- 5. Gently press and hold the registration button on the back of the thermostat (Fig 1), release when the LED starts flashing green (Fig 2).
- 6. The preferred channel LED on the controller will now be fixed green which shows the registration was successful.
- 7. Repeat steps 3 through 6 until all used room thermostats are registered.
- 8. Press and hold the OK button on the controller until the green LEDs turn off and it is just the power LED illuminated red.







Uponor Limited

Gilmorton Road Lutterworth Leicestershire LE17 4DU