

Manifold wall cabinets, replacement parts

Project information

Job name:	Location:
Engineer:	Date submitted:
Contractor:	Submitted by:
Manufacturer's representative:	Approved by:

Product information and application use

Use the hardware to mount the cabinet on the desired surface, then attach the enclosure and door. For detailed installation instructions, refer to the Uponor Recessed Wall Cabinets Instruction Sheet or the Uponor Surface-Mount Wall Cabinets Instruction Sheet on [uponor.com](http://uponor.com).



Installation

Set the manifold cabinet into the wall cavity, flush with the opening. In a 2 x 4 wall, the manifold cabinet must be inserted to the back of the stud. In a 2 x 6 wall, the manifold cabinet should be approximately 1 to 2 inches from the back of the stud. Attach the manifold box to the stud framing with wood screws. Align the four door-trim brackets with the threaded posts and wing nuts located at the top and bottom on the left and right sides of the manifold box. Slide the door-trim inward until frame is tight to the wall. Secure the frame by tightening the wing nuts. Mount the latch to the door using supplied hardware and attach the door to the door trim. For more information, refer to the Manifold Wall Cabinet instruction sheet.

Related applications

- Radiant Heating and Cooling Systems
- Snow and Ice Melting Systems
- Turf Conditioning Systems
- Permafrost Prevention (Cold Storage) Systems

Footnotes

-

Contact information

Uponor Inc.  
5925 148th Street West  
Apple Valley, MN 55124  
T 800.321.4739  
F 952.891.2008

Uponor Ltd.  
6510 Kennedy Road  
Mississauga, ON L5T 2X4  
T 888.594.7726  
F 800.638.9517