Basic end caps

Project information Job name: Location: Engineer: Date submitted: Contractor: Submitted by: Manufacturer's representative: Approved by:

Technical data

Material Brass
End type 1 ISO 228-G 1-1/4"

180 °F (82 °C) at 100 psi (6.9 bar) 200 °F (93 °C) at 80 psi (5.5 bar)

Product information and application use

The Basic End Cap terminates the end of the TruFLOW™ Jr. modular manifolds. Includes required gaskets and O-rings.

The Brass Manifold Loop End Cap closes off unused QS20 loop connections.



Part name	Part no.	A [inch]	C [inch]	E [inch]	B [inch]	Subcomponent Material	Prop 65 label required?	Weight per UOM [lbs/UOM]
Basic End Cap, R32	A2080032	2.13	2.13	0.625	-	-	-	0.25
Basic End Cap Gasket, spare part, R32	A2400032	1.58	0.125	0.125	1.58	Dezincification Resistant Brass	Yes	0.01

Part name	Part no.	Codes	Standards	Listings
Basic end caps	All	-	ASTM F877	-

Installation Related applications

The Basic End Cap threads onto one end of a brass manifold. A gasket aids the seal. Do not overtighten. The Brass Manifold Loop End Cap threads onto a brass manifold outlet. A gasket aids the seal. Do not over-tighten. For more information, refer to the Uponor Radiant Installation Handbook. Available accessories: Basic End Cap Gasket, spare part (A2400032); Loop End Gasket, spare part (A2400020).

Radiant Heating and Cooling Systems

Footnotes	Contact information		
	Uponor Inc.	Uponor Ltd.	
	5925 148th Street West	6510 Kennedy Road	
	Apple Valley, MN 55124	Mississauga, ON L5T 2X4	
	T 800.321.4739	T 888.594.7726	
	F 952.891.2008	F 800.638.9517	