

## Adaptadores con rosca macho TotalFit

| Project information            |                 |
|--------------------------------|-----------------|
| Job name:                      | Location:       |
| Engineer:                      | Fecha de envío: |
| Contractor:                    | Presentada por: |
| Manufacturer's representative: | Approved by:    |

## Technical data

 Material
 Engineered Polymer

 Temp/pressure ratings
 73 °F (23 °C) at 160 psi (11 bar)


 180 °F (82 °C) at 100 psi (6.9 bar)


 200 °F (93 °C) at 80 psi (5.5 bar)

Prop 65 label required? No

## Product information and application use

TotalFit<sup>TM</sup> is the professional-grade engineered polymer (EP) push-to-connect solution that provides greater value for residential projects with the same versatility and speed as brass push-to-connect fittings for PEX, PE-RT, CPVC, and copper piping systems.





| Part name                                       | Part no.  | End Type 1    | End Type 2 |
|---|-----------|---------------|------------|
| TotalFit Male Threaded Adapter, 1" x 1" NPT     | TF4521010 | TotalFit 1"   | MNPT 1"    |
| TotalFit Male Threaded Adapter, 1/2" x 1/2" NPT | TF4525050 | TotalFit 1/2" | MNPT 1/2"  |
| TotalFit Male Threaded Adapter, 1/2" x 3/4" NPT | TF4525075 | TotalFit 1/2" | MNPT 3/4"  |
| TotalFit Male Threaded Adapter, 3/4" x 1" NPT   | TF4527510 | TotalFit 3/4" | MNPT 1"    |
| TotalFit Male Threaded Adapter, 3/4" x 3/4" NPT | TF4527575 | TotalFit 3/4" | MNPT 3/4"  |

| Part name                               | Part no. | Codes                                     | Standards  | Listings                                      |
|---|----------|---|--|---|
| Adaptadores con rosca macho<br>TotalFit | All      | UPC IMC IPC IRC UMC NPC of Canada CPC CMC | NSF/ANSI 14 NSF/ANSI/CAN<br>61 NSF/ANSI/CAN 372 ASTM<br>F877 ASSE 1061 | IAPMO K-13573 IAPMO K-<br>13572 IAPMO K-13571 |

## Installation Related applications

Install on PEX, PE-RT, CPVC, and copper piping systems. Use deburr and depth tool to remove excess material or burrs and mark the appropriate depth on pipe. If using flexible PEX or PE-RT, install the insert inside the pipe first before making the connection. Only use PTFE thread seal tape (with a minimum of three wraps) to seal male and female adapters. Refer to the Uponor TotalFit Instruction Sheet for additional information.

Plumbing

Hydronic Heating & Cooling

| Footnotes | Contact information    |                         |  |
|-----------|------------------------|-------------------------|--|
|           | Uponor Inc.            | Uponor Ltd.             |  |
|           | 5925 148th Street West | 6510 Kennedy Road       |  |
| •         | Apple Valley, MN 55124 | Mississauga, ON L5T 2X4 |  |
|           | T 800.321.4739         | T 888.594.7726          |  |
|           | F 952.891.2008         | F 800.638.9517          |  |