υροποι


Acoplamientos TotalFit


| Project information | | |
|--------------------------------|-----------------|--|
| Job name: | Location: | |
| Engineer: | Fecha de envío: | |
| Contractor: | Presentada por: | |
| Manufacturer's representative: | Approved by: | |
| | | |

| l echnical data | | |
|-------------------------|-------------------------------------|--|
| Material | Engineered Polymer | |
| Temp/pressure ratings | 73 °F (23 °C) at 160 psi (11 bar) | |
| | 180 °F (82 °C) at 100 psi (6.9 bar) | |
| | 200 °F (93 °C) at 80 psi (5.5 bar) | |
| Prop 65 label required? | No | |

Product information and application use

TotalFit[™] is the professional-grade engineered polymer (EP) push-to-connect solution that provides greater value for residential projects with the same versatility and speed as brass push-to-connect fittings for PEX, PE-RT, CPVC, and copper piping systems.





| Part name | Part no. | End Type 1 | End Type 2 |
|-------------------------------|-----------|---------------|---------------|
| TotalFit Coupling, 1" x 1 | TF4771010 | TotalFit 1" | TotalFit 1" |
| TotalFit Coupling, 1/2" x 1/2 | TF4775050 | TotalFit 1/2" | TotalFit 1/2" |
| TotalFit Coupling, 1/2" x 3/4 | TF4775075 | TotalFit 1/2" | TotalFit 3/4" |
| TotalFit Coupling, 3/4" x 1 | TF4777510 | TotalFit 3/4" | TotalFit 1" |
| TotalFit Coupling, 3/4" x 3/4 | TF4777575 | TotalFit 3/4" | TotalFit 3/4" |

| Part no. | Codes | Standards | Listings |
|---|---|---|--|
| All | UPC IRC IPC NPC of Canada UMC CMC CPC IMC | NSF/ANSI/CAN 372 ASTM F877 NSF/ANSI/CAN 61 NSF/ANSI 14 ASSE 1061 | IAPMO K-13573 IAPMO K- 13571 IAPMO K-13572 |
| additional codes, standards, or listings: | | | |
| TF4775075 | | | |
| TF4777575 | | | |
| | All additional codes, standards, or listings: TF4775075 | All UPC IRC IPC NPC of Canada UMC CMC CPC IMC additional codes, standards, or listings: TF4775075 | All UPC IRC IPC NPC of Canada UMC CMC CPC IMC NSF/ANSI/CAN 372 ASTM F877 NSF/ANSI/CAN 61 NSF/ANSI 14 ASSE 1061 additional codes, standards, or listings: TF4775075 |

Installation

Install on PEX, PE-RT, CPVC, and copper piping systems. Use deburr and depth tool to remove excess material or burrs and mark the appropriate depth on pipe. If using flexible PEX or PE-RT, install the insert inside the pipe first before making the connection. Refer to the Uponor TotalFit Instruction Sheet for additional information.

Related applications

Plumbing

Hydronic Heating & Cooling

| Footnotes | Contact information | |
|-----------|------------------------|-------------------------|
| | Uponor Inc. | Uponor Ltd. |
| | 5925 148th Street West | 6510 Kennedy Road |
| | Apple Valley, MN 55124 | Mississauga, ON L5T 2X4 |
| | T 800.321.4739 | T 888.594.7726 |
| | F 952.891.2008 | F 800.638.9517 |