

# Ensembles TruFLOW Jr. avec vannes d'équilibrage et collecteurs sans vanne



## Renseignements sur le projet

Nom du poste :	Lieu :
Ingénieur :	Date de soumission:
Entrepreneur :	Présentée par:
Représentant du fabricant :	Approuvé par :

## Données techniques

Material	Brass
Manifold size	1 inch
Loop Cv	1.9 Cv
End type 1	ISO 228-G 1-1/4"
End type 2	ISO 228-G 3/4"
Temp/pressure ratings	73 °F (23 °C) at 160 psi (11 bar) 180 °F (82 °C) at 100 psi (6.9 bar) 200 °F (93 °C) at 80 psi (5.5 bar)
Max. fluid flow rate	14 gpm
Prop 65 label required?	Yes

## Informations sur le produit et utilisation de l'application

The TruFLOW™ Jr. Assembly with Balancing Valves and Valveless is fully assembled and ready for installation. Use the TruFLOW Balancing Hex Key on the internal balancing valves of the supply manifold to balance the loops across the manifold. The manifold body ends have R32 unions, and the loop outlets have R20 male threads.



Nom de la pièce	Numéro de pièce	A [inch]	B [inch]	C [inch]	D [inch]	E [inch]	F [inch]	G [inch]	H [inch]	I [inch]	J [inch]
TruFLOW Jr. Assembly, Balancing Valves and Valveless, 2-loop	A2660200	7.185	11.237	2.919	1.969	1.989	1.285	2.013	1.85	-	-
TruFLOW Jr. Assembly, Balancing Valves and Valveless, 3-loop	A2660300	9.154	11.237	2.919	1.969	1.989	1.285	2.013	1.969	-	-
TruFLOW Jr. Assembly, Balancing Valves and Valveless, 4-loop	A2660400	11.122	11.237	2.919	1.969	1.988	1.285	2.013	3.937	-	-
TruFLOW Jr. Assembly, Balancing Valves and Valveless, 5-loop	A2660500	13.091	11.237	2.919	1.969	1.989	1.285	2.013	5.906	-	-
TruFLOW Jr. Assembly, Balancing Valves and Valveless, 6-loop	A2660600	15.059	11.237	2.919	1.969	1.989	1.285	2.013	7.875	-	-
TruFLOW Jr. Assembly, Balancing Valves and Valveless, 7-loop	A2660700	17.028	11.237	2.919	1.969	1.989	1.285	2.013	9.843	-	-
TruFLOW Jr. Assembly, Balancing Valves and Valveless, 8-loop	A2660800	18.996	11.237	2.919	1.969	1.989	1.285	2.013	11.811	-	-

Nom de la pièce	Numéro de pièce	Weight per UOM [lbs/UOM]
TruFLOW Jr. Assembly, Balancing Valves and Valveless, 2-loop	A2660200	5.2
TruFLOW Jr. Assembly, Balancing Valves and Valveless, 3-loop	A2660300	5.16
TruFLOW Jr. Assembly, Balancing Valves and Valveless, 4-loop	A2660400	9.6
TruFLOW Jr. Assembly, Balancing Valves and Valveless, 5-loop	A2660500	9.97
TruFLOW Jr. Assembly, Balancing Valves and Valveless, 6-loop	A2660600	12.8
TruFLOW Jr. Assembly, Balancing Valves and Valveless, 7-loop	A2660700	14.1
TruFLOW Jr. Assembly, Balancing Valves and Valveless, 8-loop	A2660800	15.2

## L'installation

TruFLOW Jr. Manifolds are fully assembled ready for installation. The TruFLOW Balancing Hex Key is used on the internal balancing valves of the supply manifold. Refer to the Uponor TruFLOW Jr. Manifold Instruction Sheet for further information.

## Applications connexes

- Radiant Heating and Cooling Systems
- Permafrost Prevention Systems
- Turf Conditioning Systems

Les codes	Normes	Annonces
IMC IRC NBC of Canada UMC	CSA B137.5 R32:	cNSFus-rfh

**Remarques :**

Manifold body threaded connections:  
R32  
Manifold loop threaded connections: R20

Notes de bas de page	Coordonnées de la personne-ressource	
-	Uponor Inc. 5925 148th Street West Apple Valley, MN 55124 T 800.321.4739 F 952.891.2008	Uponor Ltd. 6510 Kennedy Road Mississauga, ON L5T 2X4 T 888.594.7726 F 800.638.9517